

KLAMATH FALLS -LMT

NORTHWEST AREA -R6

Winema National Forest

6401 Rand Way

Klamath Falls, Oregon 97603

FAX: (541) 883-6830

FTR COUNTY -KLAMATH BASE LOCATION ON FIELD -NW QUADRANT

Base Operations (541) 883-6853

Dispatch Office (541) 883-6850

Manager -Vacant (541) 883-6853

COR -Vacant (541) 883-6853

Agency Contact Frequency 169.925 tn103.5

Airtanker Base Frequency 123.975

Large Airtanker Operations Authorized? YES

SEAT Operations Authorized? YES

Hot Reloading Program Authorized? YES

Runway Weight Limits Single -110,000

Runway Weight Limits Dual -155,000

Pit Total 3

Parking Total 6-9

Known hazards: **CAUTION:** Hills north, east, and south. **CAUTION:** Birds November -May. **CAUTION:** Military flight operations, helicopters, cropdusters, and banner towing.

Remarks: Construction in Fall 2001 to Spring 2002 will change much of this information.