


## Allegro MX Backlight Adjustment

- 1) Press the **windows key** on the PDR (below the enter key) and arrow down to **Settings** and press **Enter**.




- 2) Click on the **System** tab




- 3) Click on the **Backlight** icon.




- 4) Make sure the first 2 boxes are checked in the **Battery Power** tab. You can adjust the time out to something longer than 1 minute as after 1 minute the screen will darken up.



- 5) Click on the **Brightness** tab



- 6) Make sure the **Backlight Enabled** box is checked. You can also adjust the brightness when on battery power by moving the arrow up or down



7) Click the **OK** and **X** in the next two windows to exit.

